



# 128L (ROW)

**Spare parts**

**Ersatzteile**


**Pièces détachées**

**Reserve onderdelen**

**Repuestos**

**Reservdelar**

Parts List No. 545192141		<b>Husqvarna</b> ® PARTS LIST	MODEL 128L (ROW)
Date 3/09/10	Replaces 545192141 - 8/28/09		NOTE : Illustration may differ from actual model due to design changes.




**⚠ WARNING**  
All repairs, adjustments and maintenance not described in the Operator's Manual must be performed by Qualified Service Personnel.

Ref.	Part No.	Description	Ref.	Part No.	Description
1.	★ ★ ★ ★ ★ ★	Assy-Cable/Wire Harness	18.	530015814	Screw
2.	★ ★ ★ ★ ★ ★	Housing-Throttle (RH)	19.	530015771	Screw
3.	★ ★ ★ ★ ★ ★	Screw	20.	530057554	Bracket-Shield
4.	★ ★ ★ ★ ★ ★	Screw	21.	530016014	Screw
5.	530016454	Spring-Trigger	22.	545003902	Screw
6.	★ ★ ★ ★ ★ ★	Trigger	23.	537234901	Driver Disc
7.	★ ★ ★ ★ ★ ★	Lockout-Throttle	24.	530096295	Assy-Gearbox
8.	★ ★ ★ ★ ★ ★	Housing-Throttle (LH)			
9.	★ ★ ★ ★ ★ ★	Kit-Switch			
10.	530015820	Bolt			
11.	545042201	Handle-Assist			
12.	575775301	Kit-Driveshaft SST (Incl. decal, 20,21,22,24)			
13.	530059185	Clamp-Handle			
14.	530016152	Wingnut			
15.	545007507	Flex shaft			
16.	545030901	Kit-Shield (Incl. 17,18,19)			
17.	530052286	Limiters-Line			

✓ = New Part Number For This IPL

★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)

<b>Parts List No.</b> 545192141		<b>Husqvarna</b> ® PARTS LIST	<b>MODEL</b> 128L (ROW)
<b>Date</b> 3/09/10	<b>Replaces</b> 545192141 - 8/28/09		<b>NOTE</b> : Illustration may differ from actual model due to design changes.



Ref.	Part No.	Description	Ref.	Part No.	Description	Ref.	Part No.	Description
1.	530150253	Filter	25.	530016449	Screw	47.	★★★★★	Screw
2.	530016101	Nut-Carb. Screw	26.	576382101	Starter Hsg. (KIT)	48.	★★★★★	Screw
3.	530057844	Lever - Choke	27.	545008087	Kit-Spring	49.	530015768	Locknut
4.	530058709	Bulb-Purge	28.	545008078	Kit-Starter Pulley	50.	530016456	Screw
5.	545008086	Kit-Carb. Gasket (Incl 7,62)	29.	544038802	Spring - Driver	51.	★★★★★	Assy-Fan Housing
6.	530035596	Adaptor-Carb.	30.	544038702	Pulley-Driver	52.	530150039	Assy-Clutch Drum
7.	545008084	Foam-Gasket (kit)	31.	530016468	Screw	53.	545064401	Assy-Clutch
8.	530016400	Bolt	32.	576368301	Assy-Starter Hsg. (Incl.22,23,25 - 31)	54.	530057852	Spacer
9.	952030201	Plug-Spark (RCJ-8Y)	33.	530058982	Bolt-Muffler	55.	530039242	Flywheel
10.	545008084	Seal-Cylinder (kit)	34.	530015241	Screw	56.	545195601	Crankcase-Cast
11.	545008084	Seal-Crankshaft (kit)	35.	530150440	Shield-Heat	57.	545013401	Bearing
12.	503873305	Assy-Starter Pawl	36.	530016449	Screw	58.	545195202	Assy-Crankshaft
13.	530095646	Assy-Fuel Filter	37.	576215001	Kit - Muffler Guard (Incl. Screws)	59.	530015162	Retainer-Piston Pin
14.	530069599	Kit-Fuel Line (Incl. 15)	38.	545030501	Kit-Spark Arrestor(Incl. 34)	60.	530019283	Ring-Piston
15.	530023877	Fitting-Fuel Line	39.	574031401	Kit-Muffler (Incl. 33,34,38,40)	61.	545008082	Kit-Piston/Cyl. (Incl. 59,60)
16.	530150350	Assy-Cap w/ret.(Incl. 17)	40.	545008084	Gasket-Paper Met.(kit)	62.	545008084	Seal-adaptor (kit)
17.	545008084	O-ring - Fuel Cap (kit)	41.	530015897	Screw	63.	530015897	Screw
18.	530059780	Isolator-Tank	42.	545046701	Module	64.	545081847	Kit-Carb. (Incl. 3,4,5)
19.	545180870	Assy-Fuel Tank (Incl. 13,14,15,16,17,18)	43.	530039227	Assy-Leadwire	65.	545084601	Air box
20.	576382101	Shroud-Rear (KIT)	44.	530016456	Screw	66.	530057846	Cover-Air Box
21.	530016448	Screw	45.	530016463	Washer	67.	530059796	Assy-Knob
22.	545008079	Kit-Rope	46.	530094189	Washer-Clutch	68.	545008084	Kit-Gasket (Incl. 5,7,10,11,17,40,62)
23.	545043205	Handle-Starter				69.	545180851	Kit - Decal
24.	530016426	Screw						

✓ = New Part Number For This IPL


★ = Refer to the Service Reference Indicated for more information.(Located at the END of the IPL)

<b>Parts List No.</b> 545192141		<b>Husqvarna</b> ® PARTS LIST	<b>MODEL</b> 128L (ROW)
<b>Date</b> 3/09/10	<b>Replaces</b> 545192141 - 8/28/09		<b>NOTE</b> : Illustration may differ from actual model due to design changes.

\*\*\*\*\* **Service Reference** \*\*\*\*\*


Note : Due to product improvements, your unit may have a different throttle housing assembly.  
Please refer to the serial number on your unit and order the parts below.

Serial Number - 2010-72N and lower, please use the following parts:



- Ref.# 1 - 545125301 - Assy-Cable/Wire Harness
- Ref.# 2 - 545062001 - Housing-throttle (RH)
- Ref.# 3 - 530016448 - Screw
- Ref.# 4 - 530016449 - Screw
- Ref.# 6 - 545066001 - Trigger
- Ref.# 7 - 530059804 - Lockout - Throttle
- Ref.# 8 - 545045601 - Spring - Lockout
- Ref.# 9 - 545067001 - Housing-throttle (LH)
- Ref.#10- 545030601 - Kit - Switch


Serial Number - 2010-73N and higher, please use the following parts:




- Ref.# 1 - 576139401 - Assy. - Cable/Wire Harness
- Ref.# 2 - 545223001 - Housing-throttle (RH)
- Ref.# 3 - 530016449 - Screw
- Ref.# 4 - 530015805 - Screw
- Ref.# 6 - 574355301 - Trigger
- Ref.# 7 - 574355401 - Lockout - Throttle
- Ref.# 8 - 545223201 - Housing-throttle (LH)
- Ref.# 9 - 545049309 - Switch

\*\*\*\*\* **Service Reference** \*\*\*\*\*

Note : Due to product improvements, your unit may have a different fan housing assembly.  
Please refer to the serial number on your unit and order the parts below.



- Serial Number - 2010-72N and lower, please use the following parts:
- Ref.# 46 - 530016469 - Screw
  - Ref.# 47 - 530016470 - Screw
  - Ref.# 50 - 545017501 - Assy. - Fan Housing



- Serial Number - 2010-73N and higher, please use the following parts:
- Ref.# 47 - 530015805 - Screw
  - Ref.# 48 - 530015774 - Screw
  - Ref.# 51 - 545205201 - Assy. - Fan Housing